

Serie MR 222

### Anschlussbelegung / Terminal assignment

Schalter Nr. / Switch no.	Funktion / Function	Klemmleiste / Terminal Block
<b>1</b>	COM	1
	NC	2
	NO	3
<b>2</b>	COM	4
	NC	5
	NO	6
<b>3</b>	COM	7
	NC	8
	NO	9
<b>4</b>	COM	10
	NC	11
	NO	12
<b>5</b>	COM	13
	NC	14
	NO	15
<b>6</b>	COM	16
	NC	17
	NO	18
<b>7</b>	COM	19
	NC	20
	NO	21
<b>8</b>	COM	22
	NC	23
	NO	24