


Serie ESH 80

Ausgangskanäle / Output channel


M70

cp = Rasterabstand / Click point




M74

p = Periode



Pull up (2 K $\Omega$  intern)



Line driver (RS 422)

